Item type

Chandelier

Item name

Tissot S

Item number(s)

115910

Attention!
Turn off the electricity supply at the main circuit panel before installing. Do not connect the electricity supply until your luminaire is fully assembled and installed.


Care instructions:

Wipe with a soft cloth, do not use chemicals or abrasive cleaning materials.


Eichholtz B.V.

Delfweg 52 2211 VN Noordwijkerhout The Netherlands


- ★ www.eichholtz.com
- **L** +31 (0)252 515 850




1. Connect the two pipes to the lamp and to the ceiling canopy as shown.




2. Lead the wires from your ceiling through the hole of the ceiling plate. Fix the ceiling plate to the ceiling by using mounting plugs and screws suitable to your ceiling type.




3. Slide the canopy over the ceiling plate and fix the retaining nut.



4. Hang the lamp from the suspension eye, using the chain and carabiner. Carefully lower the lamp until the chain is taut. Straighten the chain links.



5. Loosen the retaining nut and move the canopy down. Connect the 3 wires according to their colours. Brown is the live wire (L), blue is the neutral wire (N), green/yellow is the earth wire ($\frac{1}{2}$). Slide the canopy up and fix it with the retaining nut.



6. Place the bulb.